

BELKA - DX QUICK REFERENCE GUIDE

PWR	ON: Press and Hold [PWR] for 2 seconds or See: PWR ONmode at bottom
	OFF: Press and Hold [PWR] for 2 seconds, or Press [PWR] then Press [MOD]
Volume	Press [VOL]; Rotate knob; Press [VOL] 2x or W5S
Tune-Step	Press [VFO]; Rotate knob to select Step size; Press [VFO]
Fast-Tune	Press and hold [VFO]; Rotate knob while holding pressed
MEM Write	Press [MEM]; Rotate knob to select location; Press [MEM] to Save
MEM Recall	Press [MEM]; Rotate knob to select location; Press [VOL] to Recall
Mode Select	Press [MOD]; Rotate knob to select Mode; Press [MOD] 2x in CWU Mode or press [MOD] 3x in other modes
CW Pitch	In CW Mode: Press [MOD] 2x; Rotate [VFO] to select; Press [MOD] or [VFO]
Hi Cut-Off	Voice Modes: Press [MOD] 2x; Rotate [VFO] to select; Press [VFO] or 2x [MOD]
----- F O L D -----	
Low Cut-Off	All other Modes: Press [MOD] 3x; Rotate [VFO] to select; Press [VFO] or [MOD]
Sensitivity	Press [VOL], W1S, Press [VOL]; Rotate knob; Press [VFO] or [VOL] - or W5S
Display Off	OFF: Press and Hold [MOD] for 2 seconds
	ON: Press [PWR] or [MEM] or [VOL]
Lock VFO	Press and Hold [VOL] for 2 seconds; Lock indicator appears in screen.
	When in Lock, toggle display On/Off by pressing [MOD]
Menu Settings	Press [PWR]; Rotate knob to select Menu Item; Press [VFO] or [PWR] to select
TiMeR	Select time when RX will be switched OFF.
BkLight	OFF / ON / tch: light is switched on by pressing buttons or rotating [VFO]
PWR ONmode	imm: immediately; del: must hold [PWR] 2 seconds; vic: Press [VFO] then [PWR]
by DJ0IP	[VFO] = Tuning Knob W1S = Wait 1 Sec. W5S = Wait 5 Sec.

BELKA - DX QUICK REFERENCE GUIDE

PWR	ON: Press and Hold [PWR] for 2 seconds or See: PWR ONmode at bottom
	OFF: Press and Hold [PWR] for 2 seconds, or Press [PWR] then Press [MOD]
Volume	Press [VOL]; Rotate knob; Press [VOL] 2x or W5S
Tune-Step	Press [VFO]; Rotate knob to select Step size; Press [VFO]
Fast-Tune	Press and hold [VFO]; Rotate knob while holding pressed
MEM Write	Press [MEM]; Rotate knob to select location; Press [MEM] to Save
MEM Recall	Press [MEM]; Rotate knob to select location; Press [VOL] to Recall
Mode Select	Press [MOD]; Rotate knob to select Mode; Press [MOD] 2x in CWU Mode or press [MOD] 3x in other modes
CW Pitch	In CW Mode: Press [MOD] 2x; Rotate [VFO] to select; Press [MOD] or [VFO]
Hi Cut-Off	Voice Modes: Press [MOD] 2x; Rotate [VFO] to select; Press [VFO] or 2x [MOD]
----- F O L D -----	
Low Cut-Off	All other Modes: Press [MOD] 3x; Rotate [VFO] to select; Press [VFO] or [MOD]
Sensitivity	Press [VOL], W1S, Press [VOL]; Rotate knob; Press [VFO] or [VOL] - or W5S
Display Off	OFF: Press and Hold [MOD] for 2 seconds
	ON: Press [PWR] or [MEM] or [VOL]
Lock VFO	Press and Hold [VOL] for 2 seconds; Lock indicator appears in screen.
	When in Lock, toggle display On/Off by pressing [MOD]
Menu Settings	Press [PWR]; Rotate knob to select Menu Item; Press [VFO] or [PWR] to select
TiMeR	Select time when RX will be switched OFF.
BkLight	OFF / ON / tch: light is switched on by pressing buttons or rotating [VFO]
PWR ONmode	imm: immediately; del: must hold [PWR] 2 seconds; vic: Press [VFO] then [PWR]
by DJ0IP	[VFO] = Tuning Knob W1S = Wait 1 Sec. W5S = Wait 5 Sec.

BELKA - DX QUICK REFERENCE GUIDE	
PWR	ON: Press and Hold [PWR] for 2 seconds or See: PWR ONmode at bottom
	OFF: Press and Hold [PWR] for 2 seconds, or Press [PWR] then Press [MOD]
Volume	Press [VOL]; Rotate knob; Press [VOL] 2x or W5S
Tune-Step	Press [VFO]; Rotate knob to select Step size; Press [VFO]
Fast-Tune	Press and hold [VFO]; Rotate knob while holding pressed
MEM Write	Press [MEM]; Rotate knob to select location; Press [MEM] to Save
MEM Recall	Press [MEM]; Rotate knob to select location; Press [VOL] to Recall
Mode Select	Press [MOD]; Rotate knob to select Mode; Press [MOD] 2x in CWU Mode or press [MOD] 3x in other modes
CW Pitch	In CW Mode: Press [MOD] 2x; Rotate [VFO] to select; Press [MOD] or [VFO]
Hi Cut-Off	Voice Modes: Press [MOD] 2x; Rotate [VFO] to select; Press [VFO] or 2x [MOD]
----- F O L D -----	
Low Cut-Off	All other Modes: Press [MOD] 3x; Rotate [VFO] to select; Press [VFO] or [MOD]
Sensitivity	Press [VOL], W1S, Press [VOL]; Rotate knob; Press [VFO] or [VOL] - or W5S
Display Off	OFF: Press and Hold [MOD] for 2 seconds
	ON: Press [PWR] or [MEM] or [VOL]
Lock VFO	Press and Hold [VOL] for 2 seconds; Lock indicator appears in screen.
	When in Lock, toggle display On/Off by pressing [MOD]
Menu Settings	Press [PWR]; Rotate knob to select Menu Item; Press [VFO] or [PWR] to select
TimeR	Select time when RX will be switched OFF.
BkLight	OFF / ON / tch: light is switched on by pressing buttons or rotating [VFO]
PWR ONmode	imm: immediately; del: must hold [PWR] 2 seconds; vic: Press [VFO] then [PWR]
by DJ0IP	[VFO] = Tuning Knob W1S = Wait 1 Sec. W5S = Wait 5 Sec.